



2017 TILL PRESENT

Volkswagen Crafter II
MAN TGE



BEFORE PROCEEDING, PLEASE CHECK THE
PRODUCT TECHNICAL INFORMATION

REAR DOOR



Remove the paneling of the two doors of the rear door. Then proceed with the application of the template and the drilling.



In particular, the longitudinal axis of the shell is 49 cm from the lower edge of the door (see photo). Align the vertical axis (dash line) with the edge of the tailgate. Drill 9 mm holes.* *Proceed with the steps according to the generic installation procedure.*

SIDE DOOR



Remove the paneling from the door.



Then proceed with the application of the template and the drilling. In particular, the longitudinal axis of the shell is 35 m from the lower edge of the sliding guide (see photo below). Mark the 9 mm holes.* *Proceed with the steps according to the generic installation procedure.*



Because of the very good airtight seal of this type of car and cargo space, it is wise to see if it is equipped with a roof fan. If this is present, you will have no problem closing the side doors. If the van is not equipped with a roof fan, we advise you to install one to prevent problems with closing the side doors. If the customer does not want this, you will need to fill up the lock slightly before installation to guarantee a good closure.

*Pay attention to the holes on the extreme edge; before drilling, make sure that the head of the M8 pin is contained in the edge. Pay attention to the hole for the passage of the emergency cable: pierce only the external sheet to allow the insertion of the cable in the door.